## 

## Surface Fixed Akadinda Page 1 of 2



(1.1)

Instrument Components:



M10Wedge M10x30SS NutX2 Washer X2



M8x25 SS Washer X8



Eye Straps

Х2

Pin Torx 25 M8 Lock Driver Bit X1 Nut X4



M10x130 Bolt X2



5x/0mm

Screw X4

Black Caps Х8



Installation Instructions





Weight of heaviest part 28kg (Frame)



Surface Fix Components:



1. Assemble Akadinda frame

comprising 2x 'X'-shaped legs

and 1x horizontal beam. (See

2.Locate M8x80mm eye bolts

through pre drilled holes

using flat washers on both sides of the timber to prevent the fixing pulling into the timber. Secure in place with M8 nyloc nuts, cover 4 holes

in ends using 4xBlack caps.

3. Attach L Brackets to legs of

4. Place Akadinda in desired

location and mark 4 holes for

5. Fix to Surface using

recommended ground

6. Make sure all fixings are

covered and secure using cover caps provided

anchors not supplied

frame with coach bolts

(1.2)(1.3)

provided.

surface fixing.

Assembly Guide).Cover 8 holes on horizontal beam using 4xBlack caps (1.1)

> ×4 2 Part Cover Cap

Ground Anchors not supplied

Ground Surface

Spares available from www.musical-play.com or from your local distributor

Mount eye straps in the centre of the beam 360mm

beaters.

from each end to attach the

48 Kg

Install Instrument with 1.5m free space

(from widest point)

Metric Conversion:

150mm/6"

250mm/10" 360mm/14" 400mm/16"

500mm/20"

650mm/26"

750mm/30"

900mm/35"

1.5m/59"

around it.

1.5m

1.5m

1.5m

1.5m

Height to centre of notes:

KS0 3-5 500mm Depth 400mm

KS15-7650mm Depth 250mm

KS2 7-11 750mm Depth 150mm

Adult 900mm Surface Mounted

L Brackets M8x50 Coach Screw



## Assembly Guide PPAKAD

