TNTY GROUP

Ground Fixed

Akadinda Page 1 of 2



Instrument Components:





Eye Straps

X2

10x38mm

Secure Screw X4

5x70mm

Screw X4

M10 Wedge M10 x30 SS NutX2 Washer X2





M8x25SS Washer X8

M8 Lock Nut X4



M10x130 Bolt X2



Black Caps X8

Installation Instructions









Weight of heaviest part 28kg (Frame)

1. Assemble Akadinda frame comprising 2x 'X'-shaped legs and 1x horizontal beam. (See Assembly Guide). Cover 8 holes on horizontal beam using 4x30mm caps (1.1)

- 2.Locate M8x80mm eye bolts through pre drilled holes using flat washers on both sides of the timber to prevent the fixing pulling into the timber. Secure in place with M8 nyloc nuts, cover 4 holes in ends using 4x30mm caps. (1.3)
- 3. Place Akadinda in desired location and mark 4 holes for excavation.
- 4. Excavate holes to min depth 150mm according to required height for intended players. Hole depth guide below.
- 5. Locate legs in holes and check levels prior to concreting in place. Once happy with location an levels, fill holes using rapid hardening concrete. Leave to dry according to manufactures guidelines.



Height to centre of notes: KSO 3-5 500mm Depth 400mm KS1 5-7 650mm Depth 250mm KS2 7-11 750mm Depth 150mm Adult 900mm Surface Mounted





250mm/10" 360mm/14"

400mm/16"

500mm/20"

650mm/26"

750mm/30"

900mm/35"



Ground Fixed

Akadinda Page 2 of 2



Instrument Components:





M10Wedge M10x30SS Washer X2





Eye Straps M8x25SS Washer X8 X2



M8 Lock



M10x130

5x/Umm Screw X4



Black Caps X8

Assembly Guide PPAKAD

