


Installation Instructions

Surface Fixed

Cadenza
Page 1 of 3



Weight of heaviest part **7kg** (Cadenza) SD
Weight of heaviest part **13kg** (Cadenza) HD

1. Attach the steel legs to the base of the instrument with the M8 Nyloc Nuts and 2 part security caps. **(1.1)** (See Assembly Guide)



2. Attach Surface Fixing posts to legs **(1.2)** (See Ground Fix Post Installation Sheet)

3. **Locate Plate** in desired location and mark holes to fix to desired surface.

4. **Fix to Surface** using recommended ground anchors not supplied

5. Make sure all fixings are covered and secure using cover caps provided

6. Attach the 1 pair of beater to the saddle strap on the leg. **(1.3)**



Instrument Components:

- x4
M8 Nyloc Nut
- x2
M6x20 Security Screw
- x4
2 Part Cover Cap
- x1
M6 Saddle Strap

Metric Conversion:
250mm/ 10"
300mm/ 12"
450mm/ 18"
850mm/ 33"
1.5m/ 59"



- Surface Fix Components:
- x1
 - x1
 - x4

Ground Anchors not supplied



Spares available from www.musical-play.com or from your local distributor

18 - 24Kg

Assembly Guide PPCADE



Tools:

-  x1
-  x1

Surface Fixed




Cadenza
Page 2 of 3



Instrument Components:


-  x4
M8 Nyloc Nut
-  x2
M6x20 Security Screw
-  x4
2 Part Cover Cap
-  x1
Cap
-  x1
M6 Saddle Strap

Thread Lock Solution
Required (Not Supplied)









PPCADE FRONT


Thread Lock Solution
Required (Not Supplied)



PPCADE SIDE




COMPONENTS LIST:

-  2 Part Cover Cap X4
-  M8 Nyloc nut X4
-  Saddle Strap X1
-  M6x20 Pin torx X2
-  M10x70 Pin torx X2
-  M10 Barrel Nut Pin torx X2



 Pair Small Red Beaters X1

Surface Fix Components:

-  x1
-  x1
-  x4

Ground Anchors
not supplied

Spares available from
www.musical-play.com or
from your local distributor

18 - 24Kg

Surface Fix Post Installation



Tools:



Surface Fixed

Cadenza
Page 3 of 3



Components:



x1

M10 Barrel Nut



x1

M10x70 Security Screw




x4


2 Part Cover Cap

Thread Lock Solution
Required (Not Supplied)


Metric
Conversion:
50mm/ 2"
250mm/ 10"
350mm/ 14"
400mm/ 16"
450mm/ 18"



1
Locate the Surface fix Plate into the leg of the instrument.



2
Fix instrument to Surface fix plate using M10 bolt and Barrel Nut and use **thread locking solution** to prevent fixings working loose.



3
Fix Surface Plate to the ground surface **Ground Anchors Not provided** cover fixings with caps provided

Repeat Parts 1-3 for both legs