

# Installation Instructions

## Ground Fixed

Cavatina  
Page 1 of 3



### Instrument Components:

-  x4  
M8 Nyloc Nut
-  x2  
M6x20 Security Screw
-  x4  
2 Part Cover Cap
-  x1  
M6 Saddle Strap

Metric Conversion:  
250mm/ 10"  
300mm/ 12"  
450mm/ 18"  
700mm/ 28"  
850mm/ 33"  
1.5m/ 59"



Weight of heaviest part **11kg** (Cavatina)

1. Attach the steel legs to the base of the instrument with the M8 Nyloc Nuts and 2 part security caps. **(1.1)** (See Assembly Guide)



2. Attach Ground Fixing posts to legs **(1.2)** (See Ground Fix Post Installation Sheet)

3. Excavate **1 hole** for the Steel legs **250mm diameter** by **300-450mm deep** depending on Key stage, in desired location upon decision from customer.

4. Locate (lower) leg into holes making sure they are vertical and level prior to concreting in place.

5. Once happy with location of the Instrument, **fill** holes using rapid hardening **concrete**. Be sure to compact concrete around legs and leave to dry according to manufactures guidelines.

6. Attach the 1 pair of beater to the saddle strap on the leg. **(1.3)**



Pair Small Red Beaters X1

### Ground Fix Components:

-  x2  
M10x200 Bolt
-  x4  
M10 Nut



Spares available from  
[www.musical-play.com](http://www.musical-play.com) or  
from your local distributor

19.5 Kg

# Assembly Guide PPSANS




Tools:







 x1  
 x1

## Ground Fixed

Cavatina  
Page 2 of 3



### COMPONENTS LIST:

-  2 Part Cover Cap X4
-  M8 Nyloc nut X4
-  M10 Nut X4
-  M10x200 Threaded Bar X2
-  Saddle Strap X1
-  M6x20 Pin torx X2

### Instrument Components:


-  x4  
M8 Nyloc Nut
-  x2  
M6x20 Security Screw
-  x4  
2 Part Cover Cap
-  x1  
M6 Saddle Strap

M6 Saddle Strap

Thread Lock Solution  
Required (Not Supplied)

PPCAVA FRONT

PPCAVA SIDE



Pair Small Red Beaters X1

### Ground Fix Components:

-  x2  
M10x200 Bolt
-  x4  
M10 Nut


Spares available from  
[www.musical-play.com](http://www.musical-play.com) or  
from your local distributor

19.5 Kg


# Ground Fix Post Installation

## Ground Fixed


Cavatina  
Page 3 of 3



1  
Insert M10x 200 Threaded bar into pre drilled holes in Ground Fixing Post




2  
Fix M10x 200 Threaded bar in place using M10 Nuts




3  
Excavate a hole with a 250mm diameter tapering down to 350mm diameter and 350mm depth

Foundations should not present a hazard. These foundations are recommended as a guide, for more information on foundation details for various surface see Part 7 of BS EN 1176.




4  
Compact base of hole with 50mm of aggregate. Lower ground Fix post attached of instrument into hole (check instrument straight and level before filling with concrete)

300mm min depth



5  
Fill hole with fast drying concrete to manufacturers specifications.



### Components:

 x2  
M10x200 Bolt

 x4  
M10 Nut

### Metric Conversion:

50mm/ 2"  
250mm/ 10"  
300mm/ 12"  
350mm/ 14"  
400mm/ 16"  
450mm/ 18"